





CarbonClean 1000 Included Adapters

Adaptor	Part No.	Description
	063-1311	SPRING LOCK DISCONNECT TOOL
	063-1360	MANIFOLD BLOCK ASSEMBLY
	063-1361	ADAPTER 7/16" FEMALE THREAD 90
	063-1362	ADAPTER 5/16" FEMALE THREAD 90
	063-1364	ADAPTER - 5/16 & 3/8 HOSE BARB
	063-1366	ADAPTER 5/16" FEMALE THREAD STRAIGHT
	063-1367	ADAPTER 7/16" FEMALE THREAD STRAIGHT
	063-1368	ADAPTER 8MM MQDC EN PLATED
	063-1369	ADAPTER 10MM MQDC EN PLATED
	063-1370	ADAPTER 10 MM QDC FEMALE

	063-1371	ADAPTER FORD 9/16 QDC MALE
	063-1372	ADAPTER FORD 9/16 QDC FEMALE

CarbonClean 1000 Optional Adapters

Adaptor	Part No.	Description
	063-1317	Adapter - Male 14mm x 1.5
	063-1318	Adapter - Female 14mm x 1.5
	063-1322	Adapter - Male Banjo Bolt - M10 x 1.0
	063-1373	Adapter - Male Banjo Bolt - M12 x 1.25
	063-1374	Adapter - Male Banjo Bolt - M12 x 1.5
	063-1332	Adapter - Female Swivel - M12 x 1.5
	063-1333	Adapter - Male & Female Swivel - M14 x 1.5
	063-1335	Adapter - Male & Female Swivel - M16 x 1.5
	063-1339	Adapter - Honda Civic Quick Connect 6 mm - Male
	063-1375	Adapter - Honda Banjo 12 mm

	063-1376	Adapter - Nissan 11mm Male
	063-1377	Adapter - Hyundai 15 mm Male
	063-1345	Relay - Honda Fuel Pump Disable
	063-1378	Adapter - Hyundai 16 mm Male
	063-1353	Fuel Nut- Honda
	063-1354	Adapter - GM S-Bend 7/16 Female Thread